



アンプ(CE)	(3.3v)	1	2	(5v)	アンプ(VDD)
	(GPIO2)	3	4	(5v)	
	(GPIO3)	5	6	(GND)	
	(GPIO4)	7	8	(GPIO14)	
	(GND)	9	10	(GPIO15)	
	(GPIO17)	11	12	(GPIO18)	音声(右)
	(GPIO27)	13	14	(GND)	アンプ(GND)
	(GPIO22)	15	16	(GPIO23)	
赤LED(+)	(3.3v)	17	18	(GPIO24)	
緑LED(+)	(GPIO10)	19	20	(GND)	赤LED(-)
	(GPIO9)	21	22	(GPIO25)	
緑LED(-)	(GPIO11)	23	24	(GPIO8)	
	(GND)	25	26	(GPIO7)	
	(ID SD)	27	28	(ID SC)	
	(GPIO5)	29	30	(GND)	
	(GPIO6)	31	32	(GPIO12)	
音声(左)	(GPIO13)	33	34	(GND)	
	(GPIO19)	35	36	(GPIO16)	
	(GPIO26)	37	38	(GPIO20)	
	(GND)	39	40	(GPIO21)	